iPAD 2 BUMPER PLACEMENT INSTRUCTIONS



FOR iPAD 2 ONLY



TO CONVERT CRADLE FOR THE iPAD 2, PLACE BLACK ADHESIVE BUMPERS TO TOP CORNERS OF CRADLE AS SHOWN.



RMR-INS-AP8