


ENGINE CRANK CASE OIL BREATHER

Connect to 5/8 or 3/4 HOSE BARB on
ENGINE CRANK CASE OIL BREATHER CAN.
Use oil hose for this.

Oil breather fitting

LYCOMING IO-360-A1A
SAMPLE ENGINE



Designed for 5/8 or 3/4 hose barb
PN 08-00765

qqq

HOSE BARB

VENT HOLES

Mount can so that vent holes face up.
Mount can down low on the fire wall.

MOUNTING CLAMP

OIL OVERFLOW HOLE

Check CURTIS DRAIN VALVE after the first
10 hours for oil. If oil is present drain
and check every 25 hours. This will keep
the oil off the belly.

CURTIS DRAIN VALVE

For questions contact

COGSWELL ENGINEERING
2965 EVEREST WAY
CORONA, CA 92881-8345

Recommended for experimental aircraft. Not
STCD for certified aircraft.

PHONE 951-735-8679
FAX 951-278-3563